

STANDARD DEPARTURE ROUTES – INSTRUMENT (SID) ZHEZKAZGAN RWY 04	
RINUR 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 346° until intercept bearing 196°ZN, then proceed on track 016° to RINUR (N482255 E0681040). Cross RINUR at FL120 - FL150.	REMTI 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 246° until intercept bearing 026°ZN, then proceed on track 206° to REMTI (N470757 E0670843). Cross REMTI at FL120 - FL150.
DOPAR 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 007° until intercept bearing 207°ZN, then proceed on track 027° to DOPAR (N481831 E0682229). Cross DOPAR at FL120 - FL150.	ABURA 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 210° until intercept bearing 070°ZN, then proceed on track 250° to ABURA (N473345 E0664312). Cross ABURA at FL120 - FL150.
ADRIK 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 051° to ADRIK (N480432 E0684119). Cross ADRIK at FL120 - FL150.	ARMIK 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 226° until intercept bearing 086°ZN, then proceed on track 266° to ARMIK (N474512 E0664137). Cross ARMIK at FL120 - FL150.
AMASO 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 101° until intercept bearing 251°ZN, then proceed on track 071° to AMASO (N474914 E0684857). Cross AMASO at FL120 - FL150.	DINBO 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 248° until intercept bearing 108°ZN, then proceed on track 288° to DINBO (N480029 E0664647). Cross DINBO at FL120 - FL150.
ASLIK 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 180° until intercept bearing 320°ZN, then proceed on track 140° to ASLIK (N470509 E0681542). Cross ASLIK at FL120 - FL150.	BETIK 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 260° until intercept bearing 120°ZN, then proceed on track 300° to BETIK (N480807 E0665309). Cross BETIK at FL120 - FL150.
BURIK 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 203° until intercept bearing 343°ZN, then proceed on track 163° to BURIK (N470012 E0675152). Cross BURIK at FL120 - FL150.	ADOKA 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 290° until intercept bearing 150°ZN, then proceed on track 330° to ADOKA (N482224 E0671842). Cross ADOKA at FL120 - FL150.
LEMDU 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 212° until intercept bearing 352°ZN, then proceed on track 172° to LEMDU (N470002 E0674228). Cross LEMDU at FL120 - FL150.	BEDOR 3A After take-off climb straight ahead to 2000 or above. Turn LEFT on track 312° until intercept bearing 162°ZN, then proceed on track 342° to BEDOR (N482529 E0673251). Cross BEDOR at FL120 - FL150.
DITSO 3A After take-off climb straight ahead to 2000 or above. Turn RIGHT on track 237° until intercept bearing 017°ZN, then proceed on track 197° to DITSO (N470443 E0671637). Cross DITSO at FL120 - FL150.	