

STANDARD DEPARTURE ROUTES – INSTRUMENT (SID) ZHEZKAZGAN RWY 22

RINUR 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 056° until intercept bearing 196°ZN, then proceed on track 016° to RINUR (N482255 E0681040).
Cross RINUR at FL120 - FL150.

REMTI 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 186° until intercept bearing 026°ZN, then proceed on track 206° to REMTI (N470757 E0670843).
Cross REMTI at FL120 - FL150.

DOPAR 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 067° until intercept bearing 207°ZN, then proceed on track 027° to DOPAR (N481831 E0682229).
Cross DOPAR at FL120 - FL150.

ABURA 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 280° until intercept bearing 070°ZN, then proceed on track 250° to ABURA (N473345 E0664312).
Cross ABURA at FL120 - FL150.

ADRIK 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 011° until intercept bearing 231°ZN, then proceed on track 051° to ADRIK (N480432 E0684119).
Cross ADRIK at FL120 - FL150.

ARMIK 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 306° until intercept bearing 086°ZN, then proceed on track 266° to ARMIK (N474512 E0664137).
Cross ARMIK at FL120 - FL150.

AMASO 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 031° until intercept bearing 251°ZN, then proceed on track 071° to AMASO (N474914 E0684857).
Cross AMASO at FL120 - FL150.

DINBO 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 328° until intercept bearing 108°ZN, then proceed on track 288° to DINBO (N480029 E0664647).
Cross DINBO at FL120 - FL150.

ASLIK 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 100° until intercept bearing 320°ZN, then proceed on track 140° to ASLIK (N470509 E0681542).
Cross ASLIK at FL120 - FL150.

BETIK 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 340° until intercept bearing 120°ZN, then proceed on track 300° to BETIK (N480807 E0665309).
Cross BETIK at FL120 - FL150.

BURIK 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 123° until intercept bearing 343°ZN, then proceed on track 163° to BURIK (N470012 E0675152).
Cross BURIK at FL120 - FL150.

ADOKA 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 010° until intercept bearing 150°ZN, then proceed on track 330° to ADOKA (N482224 E0671842).
Cross ADOKA at FL120 - FL150.

LEMDU 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 132° until intercept bearing 352°ZN, then proceed on track 172° to LEMDU (N470002 E0674228).
Cross LEMDU at FL120 - FL150.

BEDOR 3B

After take-off climb straight ahead to 2000 or above.
Turn RIGHT on track 012° until intercept bearing 162°ZN, then proceed on track 342° to BEDOR (N482529 E0673251).
Cross BEDOR at FL120 - FL150.

DITSO 3B

After take-off climb straight ahead to 2000 or above.
Turn LEFT on track 167° until intercept bearing 017°ZN, then proceed on track 197° to DITSO (N470443 E0671637).
Cross DITSO at FL120 - FL150.