

STANDARD DEPARTURE ROUTES – INSTRUMENT (SID) TARAZ RWY 13
--

NASIP 2L

After take-off climb on track 131° to 3100 FT or above. At 6.5 NM TAR, turn LEFT on track 311° until intercept R041° TAR, after intercept R041° TAR turn LEFT to TAR climbing to 9000 FT or above(*), then proceed on track 061° to NASIP (R060.8° D29.3 NM TAR).

Cross NASIP at FL120 or above.

*Remark: If unable to reach 9000 FT until TAR, continue to reach 9000 FT over TAR.

GERPU 2L

After take-off climb on track 131° to 3100 FT or above. At 6.5 NM TAR, turn LEFT on track 311° until intercept R041° TAR, after intercept R041° TAR turn LEFT to TAR climbing to 9000 FT or above(*), then proceed on track 072° to GERPU (R071.5° D24.8 NM TAR).

Cross GERPU at FL120 or above.

*Remark: If unable to reach 9000 FT until TAR, continue to reach 9000 FT over TAR.

DODOL 2L

After take-off climb on track 131° to 3100 FT or above. At 6.5 NM TAR, turn LEFT on track 311° until intercept R041° TAR, after intercept R041° TAR turn LEFT to TAR climbing to 10000 FT or above(*), then proceed on track 152° to DODOL (R151.7° D18.0 NM TAR).
--

Cross DODOL at FL170 or above.

*Remark: If unable to reach 10000 FT until TAR, continue to reach 10000 FT over TAR.
